

YBIKE GLX PRO

OWNER'S MANUAL



IMPORTANT SAFETY NOTICE



SAFETY PRECAUTIONS:

The use of a scooter can be a hazardous activity and precautions should be taken to avoid dangerous situations. Be sure to read the entire manual before riding. Please pay close attention to the following notices in particular:

WARNING! Adult assembly required.

- Children riding the scooter should have constant adult supervision. A responsible adult must inspect the scooter prior to use, to ensure that all parts are fully assembled and tightened to prevent accidents.
- Always wear proper protective gear such as a helmet, elbow and kneepads as well as appropriate clothing such as a long sleeve shirt, gloves, long pants and trainers or closed footwear. Do not ride barefoot or in sandals.
- DO NOT use the scooter on slippery, wet or uneven ground with gravel.
- DO NOT ride the scooter with one or no hands. Hold the handlebars tightly with two hands.
- Ride the scooter only on flat and level ground. DO NOT ride the scooter on slopes. DO NOT go down a long descending slope or hill. Please be careful when passing these areas.
- Ensure that the handlebar is securely fixed and that the wheels move smoothly by turning it left and right before riding the scooter.

- DO NOT use attachments not included in packaging or attempt to do any modifications your self as this may compromise the safety of the ride-on.
- Make sure all components are assembled correctly and secured properly before riding.
- The use of the scooter is forbidden on roads used by vehicles and on all public roadways in general. Always follow and obey the local traffic laws for a safe ride.
- Never allow more than one child to ride on the scooter at any time. Not to be used by children older than 12 years or weighing more than 50kgs due to insufficient strength.

WARNING! Not for children with a body mass of more than 50kgs. **CHOKING HAZARD**—Small parts.



Injury may occur if these precautions are not observed.


NOTE: Any photos of the YBIKE GLX PRO or decals in the owner's manual are intended to be used as a reference only, and there may be some differences to the unit you purchased.

GLX PRO PARTS


Open the box and take out the parts. Please check whether all parts and components are included:

No	NAME
1	DECK
2	HANDLEBAR

GLX PRO assembly is **quick and easy!**



ASSEMBLY INSTRUCTION



Lay the deck on the ground (No.1) wheel side down. Insert the open tube of the handlebar (No.2) with the pins facing sideways into the opening provided on the front of the deck, as seen in picture A and B.

Firmly press the handlebar down until you hear the handlebar locking into position.

Give the handlebar a tug, if it feels secure, then assembly is complete!

(WARNING: Make sure the handlebar is securely fastened, and not loose)

Disassembly Instruction

To disassemble your GLX PRO, turn the deck over so that you can see the underside of the scooter. There are two pins on the right and left hand side of the handlebar. These help to lock the deck and handlebar into position. Simply push in the pins and pull the handlebar out.

Caring for your GLX PRO

1. Please clean the wheels regularly after riding . Use a moist sponge to wipe the wheels.
2. Clean handle and deck regularly.
3. Regularly check to see if all parts are securely fastened.
4. Check that all parts work and are in good condition.

CHECK BEFORE RIDING

1. Check that all the screw sets are tightened.
2. Check that the handlebar is securely fastened.
3. Check that the wheels can spin smoothly and each part is securely fixed.

WARNING! This product must be assembled by an adult. Read the manufacturer's instructions before using. Keep the instructions safe for future reference.

WWW.YBIKEUSA.COM

Designed by

WWW.CHROMECHERRY.COM