

# YBIKE EXPLORER

OWNER'S MANUAL



# IMPORTANT SAFETY NOTICE



## SAFETY PRECAUTIONS:

The use of a go-kart can be a hazardous activity and precautions should be taken to avoid dangerous situations. Be sure to read the entire manual before riding. Please pay close attention to the following notices in particular:

**WARNING!** This ride-on is intended to be assembled by an adult.

- For age group 5 to 8 years. Children riding Explorer should have constant adult supervision. A responsible adult must inspect Explorer prior to use, to ensure that all parts are fully assembled and tightened to prevent accidents.
- Always wear proper protective gear such as a helmet, wrist pads, elbow pads and kneepads as well as appropriate clothing such as a long sleeve shirt, gloves, long pants and trainers or closed footwear. Do not ride barefoot or in sandals.
- DO NOT use the Explorer on slippery, wet or uneven ground with gravel. Never use near swimming pools or other bodies of water.
- DO NOT ride the Explorer with one or no hands. Hold the handlebars tightly with two hands.
- Ride Explorer only on flat and level ground. DO NOT ride Explorer on slopes. DO NOT go down a long descending slope, driveway or hill. Please be careful when passing these areas.
- Keep your child away from doors, windows and furniture to avoid collision with glass. Block stairs/steps securely to avoid injury.


- Keep the child away from hot places, radiators, space heaters and fireplaces to avoid burns. Avoid direct, high impact collisions into walls, sidewalks and other objects.
- Ensure that the steering system is securely fixed and that the back wheel move smoothly by turning it left and right before riding Explorer
- DO NOT use attachments not included in packaging or attempt to do any modifications your self as this may compromise the safety of the ride-on.
- Make sure all components are assembled correctly and secured properly before riding.
- Never use near cars, motor vehicles, roadways, near streets or traffic. DO NOT use in traffic.
- Never allow more than one child to ride on Explorer at any time. Not to be used by children weighing more than 50 kgs due to insufficient strength.
- Always steer using both hands, one hand per handlebar. Explain to your child how to brake and stop the go-kart by using his/her feet on the pedals.
- One time assembly only. This product should only be assembled once.
- **WARNING: Chocking Hazards—Small parts. Not for children younger than 3 years old.**



**Injury may occur if these precautions are not observed.**

NOTE: Any photos of the YBIKE Explorer or decals in the owner's manual are intended to be used as a reference only, and there may be some differences to the unit you purchased.

# YBIKE EXPLORER PARTS LIST & COMPONENTS



# YBIKE EXPLORER PARTS LIST & COMPONENTS


Open the box and take out the parts. Below is a parts lists.  
Please check whether all parts and components are included:

No.	NAME
1	REAR FRAME
2	FRONT FRAME
3	CLAMPS x 4
4	REAR WHEEL
5	PLASTIC SPACER x 2
6	METAL BUSH x 2
7	WASHER x 2
8	BOLTS x 7 (FOR SHAFTS NO. 9, 10, 11) These bolts may be inserted into the shafts already.
9	CLAMP SHAFT x 4
10	REAR WHEEL SHAFT
11	STEERING HANDLEBAR SHAFT x 2
12	ALLEN KEYS SET x 2

# ASSEMBLY INSTRUCTION

## 1. Rear Wheel Assembly

Place the rear wheel (No. 4) onto the rear body (No. 1) .  
Align the wheel with the hole on the rear body,  
and insert the rear shaft (No.10).  
Tighten with bolt (No.8) using  
the Allen Keys (No. 12).




**(WARNING: Make sure bolt sets are tightened and not loose)**

## 2. Attach the clamps

Take 2 clamps (No. 3), and place each clamp on either side of the rear frame (No. 1) tube to align with the holes provided as shown in picture below.


Use the clamp shaft (No. 9) and bolt (No. 8) to slightly tighten and hold the clamps in place.




(**WARNING:** Make sure shaft sets are tightened and not loose)

### 3. Body Assembly A

Take the rear frame (No. 1) and place it between your legs so that the frame faces forward as in picture A below. Take the front frame (No. 2) with both hands slide it into the slightly tightened tube clamps (No. 3) on the rear frame until it fits together tightly and the holes align.



Insert clamp shaft (no. 9) into the last hole on the clamp (No. 3) and fasten with bolt (No. 8) to secure the front and rear frame in place as in the picture B below.




Note: Do not insert the 3rd hole shaft yet, as this will be done in the next step (4).

## 4. Body Assembly B

### Steering:

Align the 3rd open hole on the clamp with plastic spacer (No. 5), a washer (No. 7) and with the hole on the steering handlebar as in the picture below. Now insert a metal bush (No.6) into the hole, and then insert a steering handlebar shaft (No.11).


Use Allen Key (No. 12) to fasten the bolt (No.8) into the end of the steering handlebar shaft (No.11).



**(WARNING: Make sure bolt sets are tightened and not loose)**

## 5. To Adjust the Seat


Remove the four shafts and bolts from the seat using the set of Allen Keys (No.12). Now align the 4 holes on the Seat with the extra 4 holes provided on the rear frame (No.1) to change the seat position. Now insert the four shaft and bolt sets again.



**(WARNING:**  
Make sure shaft sets  
are tightened and not loose)

## 6. Caring for your Explorer

1. Please clean the wheels regularly after playing. Use a wet cloth to wipe the wheels.  
Dry the wheels thoroughly after cleaning.
2. Clean handle and seat regularly.
3. Regularly check to see if all parts are securely fastened.
4. Check that all parts work and are in good condition.



# CHECK BEFORE RIDING

1. Check that all the bolt and shaft sets are tightened.
2. Check that the steering system is securely fastened and turns smoothly.
3. Check that the wheels and pedal system can spin smoothly and each part is securely fixed.
4. Finally after checking the above points, you can now start to ride.

**WARNING!** This product must be assembled by an adult. Read the manufacturer's instructions before using. Keep the instructions safe for future reference. For children age group 5 to 8 years. Maximum weight 50 kgs. Avoid direct, high impact collisions into walls, sidewalks and other objects.

Visit

**[WWW.YBIKEWORLD.COM](http://WWW.YBIKEWORLD.COM)**